


Key and Light instruction



Error message and maintain

Err1: Incorrect password

Err2: Out of setting range

Err3: Weight is too light for calibration

Err4: Zero not allow due to weight is out of Zero range.

Err5: Scale is not stable to Tare.

Err6: No Tare due to weight is lower than 0.

A. Don't use scale in below area:

In vibrate, awing area

Directly sunshine area.

High temperature, dust, wet area.

B. AC power should have good ground to ensure safety using.

C. When use DC power, please recharge the battery on time.

When not using the scale, turn off the power.

D. NEVER use solvents (such as benzene, nitro class oil) to clean scale.

E. NO WATER and DUST to avoid damage of the scale.

F. Weighing indicator is precision measuring instrument. It ONLY can be maintained and adjust by approved engineer or our company staff. Disassembly or maintain by any other party would make the warranty invalid and could damage the scale.

Settings

Caution: Incorrect setting may stop indicator or cause unknown problem.

Press [Tare] key for a while, ----> [pd 000], and enter password 203 to enter setting menu.

F1: capacity setting [F1 CAP]

Set from 1-10000, default 200

F2: Position of decimal point [F2 dP]

Set 0-3, default 2

F3: Division [F3 Inc]

Setting 1, 2, 5, 10, 20, 50, 100, default 5

F4: Calibrate Scale [F4 CAL]

E_CAL: Zero setting

LoAd: Load weights

[XXXX.XX]: Input weight

F5: Filter setting [F5 Fit]

0: Low filter 1: Medium filter 2: High filter, default 1

F6: Auto Zero range [F6 bZ]

Could set OFF to stop Zero by key

20: 20% CAP;

50: 50% CAP;

100: 100% CAP Default 20

F7: Auto Zero tracking range [F7 AZ]

0: No Zero tracking; 1: 1d; 2: 2d; 3: 3d; 4: 4d; 5: 5d

Default 3D

F8: Power-on Zero range [F8 PZ]

OFF: no Zero when power on

20: 20% CAP;

50: 50% CAP;


100: 100% CAP Default 20

F9: Factory Default Setting [F9 Rst]


Choose 1 to load factory default settings.

Operating Manual


Installation instruction of scale



Notice: 1. Check package and make sure there is no damage.
2. Take out the parts carefully to avoid collision.




Notice: 1. Be careful to place the cable to avoid broken the cable.
2. Avoid to pull connector of cable directly.



2. Connect the indicator and load cell cable and put cable into pillar.
3. Fix indicator pillar on the scale with 3pcs M5 bolts.
4. Make the height rod through the hole of indicator installation base, then completely tight into installation base of height rod clockwise (now the distance from measurer to scale platform is 80cm)
5. Adjust right position of indicator and tighten the installation base of indicator and screws after height rod and indicator pillar are paralleled.

Notice: 1. Put the scale on flat floor during installation.



1. Only pull out slender rod when height range is in 80-140cm. The height data can be read on Pic A.
2. When height range is in 140-210cm, completely pull out slender rod and take out thick rod in middle according to height. The height data can be read on Pic B.

Notice: 1. During measuring, please pull out slender rod 1 first. Pullout thick rod in middle. 2 only after slender rod 1 is completely pull out. When reading the data, please make sure the sight is horizontal to the mark.

Operating instruction

1. **On/Off**
On: Press On/Off key. It will show model and version then ready for weighing
Off: Press On/Off key and hold for 3 seconds indicator will power off.
2. **BMI operation**
a. In standard weighing mode, a person stands on scale
b. After indicator is stable press BMI key. It will show HI 1.75 while last digit is flashing.
c. Press BMI key to move to the digit which needs to be modified. Press Print key to change the height of the person (from 0~9). Press [Tare] key to confirm input height.
d. Indicator calculate BMI automatically and show [b XX. XX]
e. Press [Tare] or [Zero] key to exit BMI mode.
3. **Zero**
When weight is in setting range press [Zero] key to make it shows "0" and [Zero] light appears.
4. **Tare**
If consider the weight on scale as tare-weight, press [Tare] key to display 0 and NET light appears.
5. **HOLD**
In standard weighing mode press [HOLD] key to hold present weight and [HOLD] light appears. If weight is in lock mode, press [HOLD] key to cancel weight, return to normal weighing mode [HOLD] light extinct.
6. **Weight Unit Convert**
In standard weighing mode press [UNIT] key for 3 seconds. The indicator will change the unit between kg and lb and correspond kg and lb will light.